

Sparklike Laser Portable™ 2.2

Options How to Send LP 2.2 to Calibration

1. DEVICE

Send the entire device to Sparklike Service Center in Finland (no change to previous model).

2. MEASURING HEAD

The Sparklike Laser Portable™ 2.2 allows you to send only the measuring head for calibration. Follow separate instructions on our website for correctly disconnecting the measuring head from the main unit.

3. SPARE MEASURING HEAD

If you have purchased an additional measuring head, it can be replaced when calibration is due. This ensures continuous operation of your device without interruptions. Send the overdue measuring head to the Sparklike Calibration Center for calibration, ensuring it is ready for use at the next calibration interval. The calibration remains valid until the next cycle, and the calibration period begins once the measuring head is connected to the main unit.

4. RENT DEVICE

To maintain continuous quality control, a fourth option is to rent a device or measuring head during calibration. Inquire about rental options from your local distributor.



Calibration process briefly:

- The device notifies that the calibration is approaching. You also get emails about the matter to the email address you have put to the Sparklike device registration form.
- Fill the form about calibration on sparklike.com
- Pack the device securely in the original Sparklike boxes to ensure safe transportation. Check the Sparklike Calibration Address on the website.
- Send the device If you want you can notify Sparklike staff about the delivery time so we are prepared.
- Device arrives to Sparklike Calibration Center and Sparklike Specialists calibrate the device / measuring head.
- Sparklike send the device to the address and contacts you.

Please note, if the device requires maintenance, send the entire device to the Sparklike Service Center in Finland. Check the current address on our website.



Sparklike